

MARTIN WISMAN MF 800

Šifra: 5936
Kategorija proizvoda: Miksete bez Snage
Proizvođač: Martin Wisman

Cena: 33.480,00 rsd

- Ultra-musical 3-band EQ+FREQ on all mono channels
- Peak LEDs all Mono Channels
- 2 Aux Send per channel for external effects and monitoring
- 2X256DSP Digital of the effect system inside
- Separate Master Mix, Headphone Outputs
- 2-Track Inputs assignable to Master Mix
- Highly accurate 12 segment Bargraph Meters

INPUT CHANNEL SECTION

1. BALANCE INPUT (MIC)

Electronially Balanced inputs acceptable a standard XLR male connector. + 48V Phantom Power available on each input Mic socket, and this switch is on Rear Phantom Power.

2. LINE INPUT

The unbalanced Mic input is provided for the use of an unbalance mic and is designed to accept an unbalanced high impedance input signal. (This use for connection Deck, Turntable, Keyboard etc..)

3. INSERT

The INSERT is a break point in the input channel signal path. It allows the signal to be taken out from the mixer, through an external equipment such as a compressor, and then back to the mixer to continue the final mix output.

4. TRIM

This has a function which adjusts the input sensitivity of each channel in order to input the constant level of the signal.

5. LOW CUT

Slide down the slide-switch, insert the 18 dB per octave 75Hz low cut filter in the signal path. This low cut filter is useful on live vocals to reduce stage rumble or "popping" from microphones. It can also be used to cut off low frequency hum.

6. HIGH

Control the high frequency tone of each channel. Always set this control to the 12 o'clock position, but you can control the high frequency tone according to the speaker, the conditions of listening position and listener's taste. Clockwise rotation of the control increases level.

7. FREQUENCY + MID

This equalization has a "bell" response i.e. having reached maximum amplification or attenuation at the selected frequency, the amplitude response returns to zero either side of that frequency. The FREQ at which this occurs is variable between 250Hz. The GAIN is variable between ± 15 dB at the selected frequency with a fixed q of 1.5Q is a factor a bandwidth.

8. LOW

Control the low frequency tone of each channel. Always set this control to the 12 o'clock position, but you can control the low frequency tone according to the speaker, the conditions of listening position and listener's taste. Clockwise rotation of the control increases the level.

9.AUX1.2

This is normally derived after the EQ section and channel fader (PRE-FADER, POSE-EQ), and is therefore unaffected by the fader position and routing status. This makes the send particularly suitable for foldback or

MARTIN WISMAN MF 800

noise 8 - Channel Mic / Line Mixer

Ultra
low

- 8 Mono Input Channels with silver plated XLRs and balanced Line Inputs
- Ultra-low noise discrete Mic Preamps with +48 V Phantom Power
- Extremely high headroom - offering more dynamic range
- Balanced Inputs for highest signal integrity

monitor feeds, which need to be controlled separately from the main P.A. Mix. All pre-fade sends may be selected internally to be PRE-FADER, PRE-EQ.

10. EFX1.2

This is normally derived after the EQ and channel fader (POST FADER, POST EQ), and is therefore follow any changers in fader level. They are normally used to drive effects processing units which are fed back into the mixer and which must fade out with the input channel.

11. PAN

The pan control sends continuously variable amounts of the post fader signal to either the left or right and G1 or G2 main busses. In the center position equal amounts of signal are sent to the left and right or G1 & G2 busses.

12. STEREO (L-R)

Push the switch, can use ST L-R fader.

During the stereo L-R switch pushed, you can't use ST L-R fader.

13. GRPS 1-2

Push the switch, can use GROUP 1-2 fader.

During the G1-2 switch pushed, you can't use stereo L-R fader.

14. PEAK

A red LED indicates a signal level at the insert return point, premaster fader, it illuminates at approximately 5 dB below clipping.

15. CHANNEL FADER

This is function to adjust the volume of signal connection into each channel and adjust the volume of output, together with master fader. Normal operating position is at the "O" mark, providing 4dB of gain above that point, if required.

MASTER SECTION

16. EFFECT PROGRAMS

When adjust switch 17, 18, 19, 20 more effects are displayed.

17. Pre-set

Push more than 5 seconds, It automatacally memorize the displayed program number. Once Just Push M1.

M2. M3. M4, always display memorized program.

18. UP TAPE SWITCH

One push, one program up push with more than 5 seconds hi-speed program up.

19. DOWN TAPE SWITCH

One push, one program down, push with more than 5 seconds, hi-speed program down.

20. MUTE

Effect ON/OFF.

21. EFFECT STEREO (L/R)

Depressing this switch, can let the EFFECT you need connect to the main control buses.

22. EFFECT GROUP(1-2)

Push the switch, can let the EFFECT you need connect to the main group buses.